**FOR THE MOST IMPORTANT PEOPLE IN THE WORLD**

# *MY CHAIR Instructions*

*PORTABLE BOOSTER*

Item# 3510

- READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF CHAIR.
- KEEP INSTRUCTIONS FOR FUTURE USE.

www.regalo-baby.com

**Regalo International, LLC.**
3200 Corporate Center Drive, Suite 100
Burnsville, MN 55306-9803, USA
Toll Free: 866-272-5274
Made in China

# ⚠WARNING:

• Prevent serious injury or death from falls or sliding out.
Failure to follow these warnings could result in serious injury or death.

• Be sure that BOOSTER SEAT is securely attached to adult chair before seating a child.
• Always secure child in the restraint until child is able to get in and out of the Booster Seat without help (about 2 1/2 years old).
• Never leave child unattended, Always keep child in view when in the BOOSTER SEAT.
• Check stability of the BOOSTER SEAT before and after seating child.
• Discontinue use if the BOOSTER SEAT is broken, Contact manufacturer immediately for replacement parts or service.
• Do not use without the anchoring strap that is used to secure the BOOSTER SEAT on to adult chair.
• Keep the BOOSTER SEAT and adult chair surface clean and try to prevent seat from slipping.
• Use only for a child capable of sitting upright unassisted.
• DO NOT USE THIS BOOSTER SEAT UNLESS ALL 4 CORNERS OF THE BOOSTER SEAT ARE SECURELY POSITIONED ON THE SURFACE OF THE ADULT SEAT.
• Do not hang objects from the BOOSTER SEAT.
• Use only on adult seats that have a solid surface.

Diagram(1)

Open the chair by pulling outward in the direction of the arrows shown in Diagram (1).

After unfolding the booster seat, it should look like the image to the right. Diagram (2)

Diagram(2)

Diagram(3)

Place the removable seat liner over the back of the seat of the booster seat.
Then secure the front of the line with the VELCRO strip.

At the back side of the My Chair there is a strap connecting to a buckle.
The strap must be tightened by adjusting the strap to its shortest length.

Diagram(4)

Diagram(5)

Diagram(6)

Wrap each end of the anchoring strap underneath the seat bottom of the adult chair and firmly connect the male and female ends of the buckle, then tighten by pulling the loose end of the strap until the booster seat is securely anchored to the adult chair, as shown in Diagram (5), next, connect the back straps around the back side of the adult chair by connecting the buckles as shown in diagram (6).
Once connected, tighten the straps to ensure they are secured.

*Note: after tightening the strap, make sure the booster seat is centred on the adult chair.

Diagram(7)

Collapse the booster seat by pushing inwards in the direction of the arrows shown in Diagram (7).

**HARNESS INSTRUCTIONS**

To Secure your child in the harness, push buckle tongues (A) into buckle housing (B) and adjust with waist strap adjusters so that the waist strap is firmly secured around child. Then, adjust the center strap between the legs of the child to ensure comfort and security.



## CARE AND MAINTENANCE

Periodically check the My Chair for sign of damage, wear or for missing components. Do not use if any part is missing, worn or damaged. Always dry metal parts to avoid the the formation of rust.

## FABRIC CARE

HAND WASH ONLY WITH DAMP CLOTH AND SOAP, AIR DRY

## 90 Days Limited Warranty:

If, during the first 90 days after consumer purchase of this item, under reasonable and non-commerical use and conditions of maintenance, it fails while owned by the original purchaser because of the quality of materials or workmanship of finish and assembly, Regalo International LLC will replace or repair it at Regalo's option,proof of purchase required.

**If you have any questions or comments contact:**
**Regalo, International**
**Toll free: 866-272-5274**
**http://www.regalo-baby.com**
**Made in China.**

**Regalo International, LLC.**
3200 Corporate Center Drive, Suite 100
Burnsville, MN 55306-9803, USA
Toll Free: 866-272-5274
Made in China

06/21/2013_DC